



BATTERY BOX LHS REAR OF TUB

TLR794802



SUITED TO:

**ISUZU D-MAX RG SERIES
MADZA BT50 TF SERIES
LDV T60**



PRE-INSTALLATION



Read through this installation guide before proceeding.



Fitting time is approx. 30 minutes.



Allen key set
Spanner
Socket Set
Drill & drill set

FITTING KIT

QUANTITY	PART
1	TLR794802
1	Battery Hold Down Clamp Kit
1	TLR810004 - Midi Fuse Bracket
4	M8 x 30 mm Hex Head Bolt
4	M8 x 20 mm Flat Washer
4	M8 Nyloc Nut
4	M6 x 20 mm Button Head Socket
4	M6 Flat Washer
4	M6 Spring Washer
4	M6 Cage Nut
2	M6 x 20 mm Hex Head Bolt
2	M6 Nyloc Nut

NOTE:

This TLR Products Battery Box is to suit a Mazda BT50 TF series, Isuzu D-MAX RG series and LDV T60, designed to mount into the rear left-hand side of the OEM tub (behind the wheel arch)

If vehicle has tub liner it will need to be modified or removed

Accommodates up to most 120AH batteries.



FITTING INSTRUCTIONS

1. If your vehicle has a tub liner you will need to trim the liner to suit the Battery Box. This will require you to place the box into position mark around the box and trim liner to suit.
2. Unpackage Battery Box and remove cover panel from main box
3. Remove the two factory bolts in the LHS rear of tub.
Note: Keep bolts for refitting at a later stage.
4. Locate Battery Box into position. Use bolts removed in step 3 to position the Battery Box.
5. Mark both holes to be drilled in the tub with a marker pen.
6. Remove Battery Box, drill marked holes in tub using 8.5 mm drill bit.
Note: Paint and rust protect with suitable product.
7. Refit Battery Box to tub using factory bolts removed in step 3.
8. In the holes drilled, use 2 x M8 Hex Head Bolts, Flat Washers and Nyloc Nut.
9. We have supplied a fuse bracket to mount 2 MIDI fuse holders to the battery clamp using 2 x M6 Hex Head Bolts and Nyloc Nuts.



hello@tlrproducts.com.au
www.tlrproducts.com.au



instagram.com/tlrproducts
facebook.com/tlrproducts