



FITTING INSTRUCTIONS FOR


# Light Cargo Barrier

SKU

**KS0716**

COMPATIBILITY

**Toyota LandCruiser LC200**



## Included contents

QTY	COMPONENT	QTY	COMPONENT
1	Light Cargo Barrier	4	M6 Aluminium Nut Block
2	Head Rest Bracket	2	M6 X 18 X 1.6 DIN Flat Washer
2	Handle Bracket (LHS & RHS)	2	M10 x 20 Button Head Socket Screw
2	Barrier Bracket (LHS & RHS)	2	M10 x 30 x 2.5 DIN Flat Washer
4	Black TPU Nut Retainer	6	M6 x 16 Flanged Hex Bolt G8.8
1	M6 x 50 Hex Bolt (Installation Tool)	2	M10 x 20 Black Plastic Knob



**Time**



30 minutes / Half a beer

Scan the **QR code** to watch the video installation guide,  
or for further information contact KAON on **07 3180 1470** or [info@kaon.com.au](mailto:info@kaon.com.au)



# It all works together.

All our storage products work together, but there is a certain order to installing.  
Let's work out the best order for your setup, shall we?



With your setup order sorted, let's get to the good part: installing. →

# Let's get to work.

## Preparing the Vehicle


1. To install with the Large Side Molle Panels or the Standalone Shelf:  
Follow the order laid out on page 2-3. This will include the installation of the handle brackets. Once complete, skip to step 15.
2. Pry off the plastic cover on the rear grab handle mounts.
3. Use a screwdriver to squeeze on the metal clips to free the grab handle.
4. Squeeze the metal clips to free them from the opening. Set aside.
5. Ensure there is 2mm of clearance around the rectangular clip opening. If required, push the lining away, or slightly trimming the roof lining.



## M6 Roof Nut Installation

**IMPORTANT:** Please read and understand the steps required to install and retain the M6 nut blocks in the roof. Refer to our Fitting Guide video (find a QR code on the cover) for more details.

6. The supplied M6 x 40 hex bolt is used to install the nut block and retainer in the roof cavity.
7. Place the retainer and nut block on the hex bolt as shown in the picture. The retainer will clip over the nut block to hold it in the roof cavity.
8. Insert the nut block into the rectangular opening in the roof. Rotate the block 90 degrees so that the raised spigot on the nut block locates in the rectangular opening.
9. While pulling back on the bolt, insert one leg of the retainer and push to clip in place.
10. Push the other leg up into the cavity and ensure that retainer is securely held in the roof and that the aluminum nut is held in place properly. Pull on the hex bolt to confirm that the aluminum nut is position properly and held securely.
11. Unwind and remove the bolt.
12. Repeat on the other side.



## Installing the Brackets

To install the **Light Cargo Barrier**:

13. Install the handle brackets to the captive nuts we installed earlier. Ensuring the nutsert is towards the front of the vehicle, tighten to secure.

To install **with the Standalone Shelf or with the Large Molle Panels**:

14. Ensure you have first followed the instructions provided with the products, then skip to step 15 below.




## Assembling the Barrier

15. Attach the barrier brackets to the barrier using the supplied M6 bolts and washers. Ensure that the barrier brackets are attached in the correct orientation. The bracket should fold towards the centre of the barrier, as pictured.



## Installing the Barrier

16. Remove the head rests and slide on the head rest brackets. Re-install the head rests with brackets in place.
17. Position the main barrier against the head rests. Ensure it is installed in the correct orientation with the warning stickers visible from the rear of the vehicle.
18. Loosely secure it to the head rest brackets using the M10 domed head bolts and M10 washer.
19. Attach the barrier bracket to the handle bracket nutsert using the M10 knob. You can adjust the position of the barrier by selecting the most suitable hole in the barrier bracket.
20. Once the barrier is in the desired position, tighten all bolts and knobs securely. That's it, you're done! The barrier can be quickly removed by removing the plastic knobs and lifting out the head rests.



# NOTICE

This barrier has not been tested to Australian Standards, and is intended as a pet barrier or for use when off-road. We cannot confirm compatible fitment of this barrier with child restraints, due to the number of possible variations. Whilst it may work with your configuration, we recommend the use of a seat belt protector where any contact occurs between any seat belt or restraint and the barrier.

## Bolt Torque

DIAMETER (mm)	5mm	6mm	8mm	10mm	12mm
NEWTON-METRES (Nm)	5 Nm	9 Nm	22 Nm	44 Nm	77 Nm



### Local Knowledge & Assistance

We know half the fun of building your dream 4x4 is getting your hands dirty. But we also know that sometimes, things don't go to plan. If in the pursuit to build the ultimate setup you find yourself off-track, we're here to help you get unstuck.

For further information call 07 3180 1470 or email [info@kaon.com.au](mailto:info@kaon.com.au)

Disclaimer: The products sold by KAON should not be modified, and are for use only on the vehicles specifically stated. KAON will not be liable for any damages arising out of the use or misuse of its products. It is the customers responsibility to ensure the products are safely and properly used and installed. KAON consistently seeks to improve its products and reserves the right to make changes to any product.